

PREFACE

• THANK YOU FOR USING •

We have purpose to provide a better life inspired by clean, hygienic and healthy lifestyles. We created design of every products with creativity but contain with comfortable and balance as a way of living. And we gladly say Thank You for believing us.

• CARE AND CLEANING •


The products is designed of years of trouble free performance. By cleaning it periodically with mild soap, rinse thoroughly with warm water, and dry with a clean, soft cloth. It make your products keep looking new. To avoid dull the finish, do not use abrasive cleaners, steel wool or harsh chemicals. Failure to follow these intructions may void your warrant.

• CAUTION •

For safe operation of the product, please observe the following :

- * Avoid too much force for operation.
- * Keep the hand hold shower on the shower arm.
- * The recommended water pressure is over 2kg²/cm².
- * Do not dismantle the products without manual.

• TOOLS YOU WILL NEED •




• BEFORE YOU START INSTALLATION •

OBSERVE ALL LOCAL PLUMBING CODES





- * Make sure water supply is shut off.
- * Read these instructions carefully to ensure proper installation.
- * Our product reserves the right to update product design without notice.

DESCRIPTION

* Check to make sure you have the following parts indicated below.




Shower Head

 Hexagonal Wrench 1x	 Hexagonal Bolt 1x	 Flow rate Regulator 1x	 Filter 1x
---	---	--	---

7T SQUARE HEAD

CODE	Ball joint type SO200.001.CR - SO240.001.CR - SO300.001.CR - SO350.001.CR - SO400.001.CR Without Ball joint type SO200.002.CR - SO240.002.CR - SO300.002.CR - SO350.002.CR - SO400.002.CR
SIZE	200x200 mm - 240x240 mm - 300x300 mm - 350x350 mm - 400x400 mm
FINISH	Chrome Plating
ORIGIN	JoeyforLife / South Korea

DESCRIPTION




DIMENSION

FLOW RATE


Water Pressure	200	240	300	350	400
1 Bar	8	7.3	7.3	17.4	17.5
2 Bar	9.6	9	9	22.5	22.9
3 Bar	9.7	9	9	27	28.6
4 Bar	10	9.5	9.7	27	28.6

*Direct Connection Without Tap




INSTALLATION

INSTALLATION PROCEDURE




1.

Insert the flow rate regulator and washer on the ball joint valve.



2.

Connect the shower head tightly.



3.

Fix the shower head with bolt.

Overhead Shower - 7T Square

INSTALLATION GUIDE BOOK

