




8. Connect water supply hoses to the shower head.



9. Put the shower head to the bracket.  
Fix the head with 4 bolts.



• THANK YOU FOR USING •

We have purpose to provide a better life inspired by clean, hygienic and healthy lifestyles. We created design of every products with creativity but contain with comfortable and balance as a way of living. And we gladly say Thank You for believing us.

• CARE AND CLEANING •

The products is designed of years of trouble free performance. By cleaning it periodically with mild soap, rinse thoroughly with warm water, and dry with a clean, soft cloth. It make your products keep looking new. To avoid dull the finish, do not use abrasive cleaners, steel wool or harsh chemicals. Failure to follow these intructions may void your warrant.

• CAUTION •

For safe operation of the product, please observe the following :

\* Operating pressure :

Minimum Pressure .... 1 bar (Flowing Pressure)  
Maximum Pressure .... 6 bar (Flowing Pressure)

\* Hot water supply temperature must not extend 80°C

\* Do not use steam for hot water supply

\* Do not use the product at ambient temperature below 0°C


• TOOLS YOU WILL NEED •




Wrench



Drill




Saw




Hammer



Pencil





Screwdriver





3. Screw 4 stud bolts (M6x1.0P) to the anchor bolts and fasten each bolt with a nut.

4. Check the length between the upper ceiling and built-in bracket.  
Cut the stud bolts according to the measured value.  
Put one nut to each stud bolt.  
It must be 20mm gap between stub bolt and ceiling.






5. Put the bracket to the ceiling.

6. Tighten the stud nuts with 4 nuts and adjust the height.




7. Hang wires of the head on the bracket.



Bracket Size


INSTALLATION PROCEDURE



1. Cut the ceiling to install the bracket and mark 4 positions on the upper ceiling for anchor bolts.  
 SMB380.002.CR : 354 x 354 mm  
 SMB430.002.CR : 404 x 404 mm  
 \*(Error range ±10mm)

2. Make the 4 holes (Ø12 mm) on the 4 marks. Put the 4 strong anchors to holes and hit them with a hammer.


SMB380.002.CR : 310 x 256 mm  
 SMB430.002.CR : 360 x 305 mm




• BEFORE YOU START INSTALLATION •

OBSERVE ALL LOCAL PLUMBING CODES

- \* Make sure water supply is shut off.
- \* Read these instructions carefully to ensure proper installation.
- \* Our product reserves the right to update product design without notice.
- \* Check to make sure you have the following parts indicated below.



Shower Head




Bracket



Filter  
1x



Stud Bolt  
4x




Nut  
12x



Wire  
4x



Strong Anchor Bolt  
4x



Bolt  
4x


INFORMATION

CODE	SMB380.003.CR	SMB430.003.CR
SIZE	380 x 380 mm	430 x 430 mm
FINISH	Chrome Plating	

FLOW RATE

Water Pressure	(L/min)	
	380	430
1 Bar	11	14
2 Bar	16	19
3 Bar	20	23
4 Bar	24	26

\*Direct Connection Without Tap



DIMENSION

